










Hand Air Pump for pneumatic Engines

For use on Lego pneumatic engines. A pressure of 3 psi can be reached.





Base Construction: Nico71


Modification and Instructions: Alex Zeimet





5




7







6




8






10



11



Connect to the
pneumatic engine

